



9500HS222 Owners Manual

The instrument cluster display must be set to “Audio Mode” in order for radar messages to appear

Basic Escort 9500ci commands may be compatible with your vehicle. Please see the command list below.

Steering wheel controls for the 9500HS222 are as follows:

Volume (mute during alert) = VCS Off + MUTE

Sensitivity= VCS Off + SEND (phone pick up)

Mark Location= VCS Off + END (phone hang up)

